

aurora tools®

Model XC949 - 500W HALOGEN WORK LIGHT

IMPORTANT: Read this information before use



1. Insert stand base (1) into other end of tube. Use the stand handle (2) to position the lamp to the desired angle. Insert and tighten angle adjustment knob (3).



2. Lamp angle may be altered simply by loosening the angle adjustment knob (3), moving the stand handle to bring the lamp to the desired angle, then tightening the angle fixing knob.

INSERTING OR REPLACING HALOGEN LAMP


IMPORTANT: ensure unit is disconnected from power source. Allow time for unit to cool before handling




1. Unscrew retaining screw on top of lamp. This will release the protective grill, front surround and glass faceplate



2. Lower front surround down. It will be retained by the hinges



3. To insert halogen tube: unwrap bulb, taking care your fingers do not touch the bulb. Use wrapping to handle the bulb. Push one end of tube into either of the spring-loaded sockets. Locate other end on other socket, and release.



4. Carefully replace front surround, making sure that it is correctly positioned. Screw tightly.

INSTRUCTIONS TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION, OR INJURY TO PERSONS

IMPORTANT SAFETY INSTRUCTIONS

LIGHTED LAMP IS HOT!

- 1- Turn off/unplug and allow to cool before replacing bulb
- 2- Bulb gets hot quickly
- 3- Do not touch hot lens and guard of enclosure
- 4- Do not remain in light if skin feels warm
- 5- Do not look directly at lighted bulb
- 6- Keep lamp away from materials that may burn
- 7- Use only with a 500 watt or smaller bulb
- 8- Do not touch the bulb at any time. Use a soft cloth. Oil from skin may damage bulb.
- 9- Do not operate the unit with a missing or damaged guard, lamp containment barrier or UV filter

WARNING:

- A) Use only 3-wire outdoor extension cords that have 3-prong grounding plugs and grounding receptacles that accept the appliance's plug.
- B) Ground fault circuit interrupter (GFCI) protection should be provided on the circuit(s) or outlet(s) to be used for the wet location portable lamp. Receptacles with built in GFCI protection and compliant to this safety measure are available.
- C) Use only with an extension cord for outdoor use such as a type SW, SW-A, SOW, SOW-A, STW, STW-A, STOW, STOW-A, SJW, SJW-A, SJOW, SJOW-A, SJTW, SJTW-A, SJTOW, or SJTOW-A extension cord.

SAVE THESE INSTRUCTIONS