auroratools°

Model No. XG816 22W LED WORK LIGHT - 1500 LUMENS



Read and understand all safety and operating instructions before using this product.

ASSEMBLY INSTRUCTIONS

Do not assemble while plugged into power.

- 1. Locate the light housing and stand.
- 2. Turn the light on its side and position the U-shaped bracket against the stand.
- 3. Remove the screws from stand, and connect the U-shaped bracket and stand.
- 4. Adjust the lamp head and it's ready to use.

OPERATION

- 1. To adjust the lamp head position: Loosen the knob on the side, tilt the lamp head to the desired position and re-tighten the knob.
- 2. Always turn the lamp head OFF before unplugging the work light.

WARNING: Risk of personal injury. To avoid being burned, always hold the work light by its grip on the handle when making adjustments.

BULB REPLACEMENT

The LED bulb is not designed for a replacement, as it is produced for a lifetime up to 30,000 hours. If the LED bulb fails to function, please contact a qualified electrician.

SAFETY INSTRUCTIONS

CAUTION: Read and understand all Safety and Operating instructions in this manual before using this product.

DANGER: BE EXTREMELY CAREFUL WHEN USING THIS DEVICE. Improper use of this work light can result in injury or death.

WARNING: Failure to observe the following safety rules may result in FIRE, ELECTRICAL SHOCK, INJURY, or EXPOSURE TO EXCESSIVE ULTRAVIOLET RADIATION.

In addition to normal safety precautions when working with electrical devices, it is recommended to follow all safe guards stated in this manual. When using outdoor-use Portable Lamp Stand / Tripod work lights, always follow basic safety precautions to reduce the risk of fire, electric shock and personal injury.

- 1. Use only 3-wire UL listed outdoor extension cords that have 3-prong grounded plugs and grounded receptacles that accept the work light's plug.
- 2. Ground Fault Circuit Interrupter (GFCI) protection should be provided on the circuit(s) or outlet(s) when using the work light in humid locations
- 3. Use only with an 18 -gauge (AWG) extension cord of cord type SW-A, SOW, SOW-A, STW, STW-A, STOW-A, STOW-A, SJW, SJW-A, SJOW, SJOW-A, SJTW-A or SJTOW, SJTOW-A.
- 4. If exposed skin feels warm while you are in the lighted area, move the work light farther away.
- 5. Do not look directly at the lighted lamps to avoid eye injuries.
- 6. Always keep the work light away from any flammable surfaces or materials.
- 7. Do not operate work light if it has a missing or damaged lens cover.
- 8. Never use around heavy volatile fluids such as gasoline.
- Do not use with an extension cord near water, or in areas where water may accumulate.Keep work light at least 16 feet from pools or spas. Keep plugs dry. Recommended for humid location use only with GFCI protected.

