



Magnetic Sweeper Instruction Manual

Model No. UAK050

1. Attach the Handle to the Magnet Base (Figure 1)

Assemble the handle sections using the hex screws/washers and nuts. Slide the open end of the handle (A) over magnet assembly stem and align holes. Insert the hex bolt and secure from the underside with a locking nut. Tighten firmly.

2. Attach Release Bar (Figure 2)

Attach top of release bar (C) to pull lever by aligning holes and placing a hex bolt through a washer and into the Pull lever hole (B). Place a washer between the release bar (C) and pull lever (B), Then secure the washer with a locking hex nut.

3. Attach Wheel (Figure 3)

Slide each wheel onto the threaded bolts on each side and secure with the hex nuts. Do not over tighten, wheels must be able to spin freely.

