


Model No. TYY302

MANUAL OF DIGITAL MEASURING WHEEL PLEASE READ THE MANUAL BEFORE USE.

Thank you for choosing our products, the digital measuring wheel is suitable for long distance measuring, widely used for road or ground measuring e.g. construction, playground, garden, etc.... And measuring of steps as well. It is a cost-effective measuring wheel with high technology and ergonomic design, easy to use and durable.





1. MAIN PARTS:





2. TECHNICAL DATA:

- a. Max measuring range: 99999.9m 99999.9inch
- b. Accuracy: 0.5%
- c. Resolution: 0.1 m
- d. Power: 3V(2XLR3 batteries)
- e. Suitable temperature: -10°C – 45°C
- f. Diameter of the wheel: 318 mm

3. BUTTOM OPERATION:



1. ON/OFF: power on or off
2. m/ft: shift between metric and inch system. m stands for metric, ft stands for inch system.
3. sm: store memory. After measurement, push this button, you will store the measured data in memory m1, 2, 3... pic1 shows the display.
4. Rm: recall memory. Push this button to recall the stored memory in M1...M5. If you store 5 M in M1, 10m in M2, which the current measured data is 120.7 M, after you push the button rm once, it will display the data of M1 and an additional R sign at the right corner. After several seconds, it will show the current measured data again. (see Pic 2). If you push the rm button twice, it will show the data of M2 and an additional R sign at the corner. After several seconds, it will show the current measured data again. (see Pic 3)
5. CLR: Clear the data. Push this button to clear the current measured data.



4. WARNING:

1. If you measure a straight line, make sure to walk straightly.
2. Do not measure uneven surface, otherwise the accuracy cannot be guaranteed.
3. Do not use it in the rain for a long time.
4. Do not use it in high temperature environment as well as store it.
5. If the display is dark and the battery sign appears, please replace the batteries.
6. Do not dispose of batteries freely, please recycle it at specified places.
7. If you will not use this instrument for a long time, remove the batteries and store it in dry suitable place.
8. Do not use it as a toy to avoid extra injury.