



# Model No. XG817

## 40W LED WORK LIGHT WITH TRIPOD

### 4800 LUMENS

#### IMPORTANT:

Read and understand all safety and operating instructions before using this product.

**WARNING:** Risk of personal injury. To avoid being burned, always hold the work light by its grip handle when making adjustments.

**WARNING:** Failure to observe the following safety rules may result in FIRE, ELECTRICAL SHOCK or INJURY.

#### ASSEMBLY INSTRUCTIONS

**Do not assemble while plugged into power.**

**DANGER:** BE EXTREMELY CAREFUL WHEN USING THIS DEVICE. Improper use of this work light can result in serious injury.

##### LIGHT STAND ASSEMBLY

1. Locate the light housing and stand.
2. Turn light on its side and position the U-shaped bracket against the stand.
3. Remove screw from the stand, and connect the U-shaped bracket to the stand.

##### WORK LIGHT ASSEMBLY

1. Loosen screw on the side, adjust the lamp head to desired position and re-tighten screw.
2. Turn off lamp before unplugging.

#### BULB REPLACEMENT

The LED bulb is not designed for replacement; it has a life span of approximately 30 000 hours. If the LED bulb fails to work, contact a qualified electrician for further inspection.

#### OPERATION

##### TELESCOPING POLE OPERATION

1. Unpack fixture and place all parts on a smooth surface.
2. Adjust the legs to up or down position by loosening the knob. Do not adjust the legs by force. Legs must be fully extended to ensure stable operation.
3. Adjust the telescopic pole to desired height by loosening and tightening lock nuts located at the top of each extension
4. Mount light fixture assembly to the top of the telescope pole turning the center knob clockwise until secure. Do not over-tighten the center knob.
5. The work light is now ready for use.

**WARNING:** Risk of personal injury. To avoid being burned, always hold the work light by its grip on the handle when making adjustments.

#### SAFETY INSTRUCTIONS

**CAUTION:** Read and understand all Safety and Operating instructions in this manual before using this product.

**Follow all safeguards stated on this page, in addition to normal safety precautions in working with electrical devices. When using the work light outdoors, always follow basic safety precautions to reduce the risk of fire, electric shock and personal injury.**

1. Use only 3-wire UL listed outdoor extension cords with 3-prong grounded plugs, as well as grounded receptacles that accept the work light's plug.
2. Ground Fault Circuit Interrupter (GFCI) protection should be provided on the circuit(s) or outlet(s) when using the work light in humid locations.
3. Use a minimum 18-gauge (AWG) extension cord of cord type SW-A, SOW, SOW-A.STW, STW-A, STOW, STOW-A, SJW, SJW-A, SJOW, SJOW-A, SJTW-A or SJTOW, SJTOW-A.
4. If exposed skin feels warm while in lighted area, move work light farther away.
5. Do not look directly at the lighted lamps to avoid eye injuries.
6. Always keep the work light away from any flammable surfaces or materials.
7. Do not operate work light if it has a missing or damaged lens cover.
8. Never use around volatile fluids such as gasoline.
9. Do not use near water, or in areas where water may accumulate. Keep work light at least 16 feet from pools or spas. Always keep plugs dry. Recommended for humid location use only with GFCI protected cords.

